

# DENALI

MOTORCYCLE LIGHTING & ELECTRONICS

## Denali Horn Mount Kawasaki KLR650E

### PLEASE READ BEFORE INSTALLING

TWISTED THROTTLE products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. TWISTED THROTTLE takes no responsibility for damages caused by improper installation.

All screws, bolts, and nuts, including all replacement hardware provided by TWISTED THROTTLE should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M5.....	3.5 ft-lbs (5 Nm)
M6.....	7 ft-lbs (9.6 Nm)
M8.....	13 ft-lbs (18 Nm)

All screws, bolts, and nuts should be checked after driving the first 30 miles (50 km) to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts, and nuts.

Hardware	
"L" Bracket	1x
Hex-Head Screw; M6 x 25	1x
Washer; M6	1x
Spacer; 7mm	1x



Attach the mounting bracket with the M6 screw provided. Place the 7mm spacer behind to the bracket.



Mount the horn to the bracket using the hardware provided with the horn. Be sure to read all mounting instructions provided with the horn to ensure it is mounted at the right angle.