

# Barkbusters

www.barkbusters.net


## Preparation: KAWASAKI Z125 PRO

Remove original bar end plug.

## Fitting Procedure:

(repeat for other side with applicable parts)

- Loosely assemble clamp (3) below the bend of the handlebar and position as shown in image below.
- Loosely attach the handguard backbone with applicable parts to the handlebar end and also to the clamp.
- Note:** The preferred backbone position is horizontal when viewed from the side.
- Tighten all bolts in the following order (8), then (7), then (5 and 6).
- Use recommended torque specifications over page.



### FITTING TIP: Kawasaki Z125 PRO

Clamp is positioned below the bend of the handlebar as shown.

INS-BHG-063-00-NP

## FITTING INSTRUCTIONS for...

- KAWASAKI Z125 PRO ('16 on)
- HONDA MSX125 GROM ('14 on)

## Preparation: HONDA MSX125 GROM


Remove original handlebar end weight and screw. **NOTE:** Retain original weight.

## Fitting Procedure:

### Fitting Procedure shown for the RIGHT side

(repeat for left side with applicable parts)


- Loosely assemble clamp (3) to the handlebar with applicable parts.
- FITTING TIP:** Clamp is positioned at the handlebar bend.
- Loosely attach the handguard backbone with applicable parts to the handlebar end and also to the clamp.
- Note:** The preferred backbone position is horizontal when viewed from the side.
- Tighten all bolts in the following order (9), then (7), then (5 and 6).
- Use recommended torque specifications over page.



**RIDEXORX**

<b>1</b> Aluminium Bar  PN: BAR-V-020-L Pcs. 1 (Left)	<b>2</b> Aluminium Bar  PN: BAR-V-020-R Pcs. 1 (Right)	<b>3</b> Clamp Frame & Saddle (left)  PN: CFS-ADV-L Pcs. 1 set	<b>4</b> Clamp Frame & Saddle (right)  PN: CFS-ADV-R Pcs. 1 set	<b>5</b> Button Head Bolt 30mm  PN: M6x30BHCSZP Pcs. 2	<b>6</b> Button Head Bolt 20mm  PN: M6x20BHCSZP Pcs. 2	<b>7</b> Flat Head Bolt 20mm  PN: M8x20FHCSZP Pcs. 2	<b>8</b> Flat Head Bolt 65mm  PN: M8x65FHCSZP Pcs. 2						
<b>9</b> Flat Head Bolt 60mm  PN: M6x60FHCSZP Pcs. 2	<b>10</b> Spacer  PN: BSSRT20 Pcs. 2	<b>11</b> Expander  PN: BBE17 Pcs. 2	<b>12</b> Taper Nut  PN: NUT12 Pcs. 2	<table border="1"> <thead> <tr> <th colspan="2">Recommended Torque Settings</th> </tr> </thead> <tbody> <tr> <td>M6</td> <td>10 Nm (7.4 lbf ft)</td> </tr> <tr> <td>M8</td> <td>20 Nm (14.8 lbf ft)</td> </tr> </tbody> </table>		Recommended Torque Settings		M6	10 Nm (7.4 lbf ft)	M8	20 Nm (14.8 lbf ft)	<p><b>Personalise Your Protection</b> Guard options sold separately</p> <p><b>JET</b> JET-003  <b>VPS</b> VPS-003  <b>Storm</b> STM-003  <b>CARBON</b> BCF-003</p>	
Recommended Torque Settings													
M6	10 Nm (7.4 lbf ft)												
M8	20 Nm (14.8 lbf ft)												

**See below for correct bar orientation**



**NEXXS** MOTORCYCLE PARTS  
株式会社 ネクサス

nexxs 検索 nexxs.co.jp  
E-Mail : mc@nexxs.co.jp  
TEL : 06-6333-1777



**CAUTION:**

Installation of the handguard is safety-relevant work and can be complicated. We recommend the installation be performed by a motorcycle service technician. Rideworx accepts no liability for damages caused by improper mounting. All screws, bolts and nuts, including all replacement hardware provided by Rideworx, should be tightened to the torque specified in the table. After the first 50km of riding check all screws, bolts and nuts are tightened to the correct torque. We recommend a medium strength liquid thread lock product on all fasteners.

**WARNING:**

Check operation of all handlebar controls, specifically the throttle, front brake, kill switch and clutch to ensure they are operating correctly and are in accordance with the OEM specifications. Do not ride the motorcycle if any controls are not operating correctly or if rear view mirror vision is obscured. Check periodically that all bolts are tight.

**Disclaimer:**

A failure to follow these fitting instructions could cause serious injury, death or property damage. These handguards are intended solely for use with motorcycles/ATV/snowmobiles/scooters that have not been modified. They are not designed to prevent injury or death while riding or in an accident or crash. The user must ensure that all controls are free of the handguards every time that they ride. By installing and/or using this product you acknowledge that you accept these terms and have followed the fitting instructions.