



**FITTING INSTRUCTIONS FOR CP0430BL
NON-DRILL AERO CRASH PROTECTORS
TRIUMPH STREET TRIPLE S, R & RS 765 '17-**



Picture A




Picture B

**THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.**

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)




Left Side

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



Right Side

LEGEND

- ITEM 1 = CRASH PROTECTOR CAPS (BC0002) (x2).
- ITEM 2 = CRASH PROTECTOR (B0061 with CS341) (x2).
- ITEM 3 = AERO SPACER (S0533 with CS437) (20mm LONG) (x1).
- ITEM 4 = M10 PLAIN WASHERS (x8).
- ITEM 5 = M10x1.25x140mm LONG HEX HEADED BOLTS (x1).
- ITEM 6 = M10 NYLOC NUT (x2).
- ITEM 7 = SPACER (S0587) (48mm LONG) (x1).
- ITEM 8 = M10x1.25x60mm LONG BUTTON HEAD BOLTS (x2).
- ITEM 9 = MOUNTING BLOCK (M0334) (x1).
- ITEM 10 = LOCK-WASHERS (LW0001) (x2).
- ITEM 11 = M10x1.25x80mm LONG HEX HEADED BOLTS (x1).
- ITEM 12 = M10x1.25x70mm LONG HEX HEADED BOLTS (x1).
- ITEM 13 = MOUNTING BLOCK (M0335) (x1).
- ITEM 14 = SPACER (S0424) (32mm LONG) (x1).
- ITEM 15 = M10x1.25x120mm LONG HEX HEADED BOLTS (x1).
- ITEM 16 = AERO SPACER (S0588 with CS448) (12mm LONG) (x1).
- ITEM 17 = SPACER (S1038) (7mm LONG) (x1).


Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

TOOLS REQUIRED


- Socket set to include 14 & 17mm socket and wrench.
 - 14 & 17mm spanner.
- Socket set to include 6mm A/F.
 - Torx set to include T50.
- Torque wrench (up to 40Nm).




TOWARDS REAR
OF BIKE



TOWARDS FRONT
OF BIKE



PICTURE C



Picture 1




Picture 2



Picture 3



Picture 4



Picture 5



Picture 6



Picture 7



Picture 8

FITTING INSTRUCTIONS

Left-side (as you sit on the bike)

- Remove the two T50 Torx bolts that mount the engine to the frame, as shown in picture 1, (there is a 14mm nut on the rear of the front bolt that can be accessed using a spanner).
- Take the left-side mounting block (item 9 – M0334) and locate the M10 x 140mm long hex headed bolt (item 5) through the mounting hole nearest to the machined bobbin profile. Please fit one M10 washer (item 4) on the bolt before inserting through the hole, and position the spacer (item 7 – S0587 – 48mm long) onto the exposed thread, as shown in picture 2.
- This assembly can now be offered up to the bike, with the bolt locating into the front frame/engine mount.
- Take one M10 x 60mm long button head bolt (item 8) and fit one M10 washer, before inserting through the rearward hole on the mounting block and into the rear frame/engine mount, before loosely tightening.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



- With the front mounting bolt now protruding through the frame/engine mount, one M10 washer and M10 nyloc nut can be fitted to the exposed thread. This can be accessed using a 17mm spanner.
- Now tighten both bolts. The bolt at the rear needs to be tightened (do not exceed 40nm of torque) whilst the bolt at the front needs to be tightened until you feel the compression increase slightly. Then apply a quarter turn. *Do not overtighten – the nyloc nuts will hold it tight.*
- Now it's time to fit the bobbin to the mounting block. To do this, slide one M10 washer onto the M10 x 80mm hexagon headed bolts (item 11) so the washer sits against the head of bolt.
- Slide one serrated locking washer over the bolt so it sits against the washer just fitted.
- Next slide the bolt and washers through either crash protector so the head of the bolt goes into counter-bore in the crash protector, as shown in picture 3.
- Place the longer aero spacer (item 3 – S0533 20mm long) onto the exposed thread of the bolt and offer the assembly up to the threaded boss on the mounting block, as shown in picture 4.
- Tighten the crash protector assembly until you feel some compression from inside the protector using a 17mm socket and wrench. **PLEASE NOTE THE CRASH PROTECTOR MUST BE POSITIONED AS IN PICTURE C ABOVE WITH BIGGER END TOWARD FRONT OF BIKE.** Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not over-tighten as damage can occur to the bike. Do not exceed 40nm of torque.
- If not already fitted fit bubble sticker into recess of the crash protector cap.
- Fit the crash protector cap into the crash protector.

Right-side (as you sit on the bike)

- Remove the two T50 Torx bolts that mount the engine to the frame, as arrowed in picture 5, (there is a 14mm nut on the rear of the front bolt that can be accessed using a spanner).
- Take the right-side mounting block (item 13 – M0335) and locate the M10 x 120mm long hex headed bolt (item 15) through the mounting hole nearest to the machined bobbin profile. Please fit one M10 washer (item 4) on the bolt before inserting through the hole, and position the spacer (item 14 – S0424 – 32mm long) onto the exposed thread, larger diameter first, as shown in picture 6.
- This assembly can now be offered up to the bike, with the bolt locating into the front frame/engine mount.
- Take one M10 x 60mm long button head bolt (item 8) and fit one M10 washer, before inserting through the rearward hole on the mounting block and then locate the short spacer (item 17 – S1038 – 7mm long) onto the exposed thread of the bolt and locate into the rear frame/engine mount, before loosely tightening, as shown in picture 7.
- With the front mounting bolt now protruding through the frame/engine mount, one M10 washer and M10 nyloc nut can be fitted to the exposed thread. This can be accessed using a 17mm spanner.
- Now tighten both bolts. The bolt at the rear needs to be tightened to the manufacturers recommended torque setting (do not exceed 40nm of torque) whilst the bolt at the front needs to be tightened until you feel the compression increase slightly. Then apply a quarter. *Do not overtighten – the nyloc nuts will hold it tight.*
- Now it's time to fit the bobbin to the mounting block. To do this, slide one M10 washer onto the M10 x 70mm hexagon headed bolts (item 12) so the washer sits against the head of bolt.
- Slide one serrated locking washer over the bolt so it sits against the washer just fitted.
- Next slide the bolt and washers through either crash protector so the head of the bolt goes into counter-bore in the crash protector, as shown in picture 7.
- Place the shorter aero spacer (item 16 – S0588 12mm long) onto the exposed thread of the bolt and offer the assembly up to the threaded boss on the mounting block, as shown in picture 8.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



- Tighten the crash protector assembly until you feel some compression from inside the protector using a 17mm socket and wrench. **PLEASE NOTE THE CRASH PROTECTOR MUST BE POSITIONED AS IN PICTURE C ABOVE WITH BIGGER END TOWARD FRONT OF BIKE.** Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not over-tighten as damage can occur to the bike. Do not exceed 40nm of torque.
- If not already fitted fit bubble sticker into recess of the crash protector cap.
- Fit the crash protector cap into the crash protector.

ISSUE 1 03/07/2017 (AR)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.