



LAH.04.10600
 KTM 1290 Super Adventure R
 Center S4 Mounting Bracket

Thank you for choosing DENALI

We know you would rather be riding your bike than wrenching on it, so we go the extra mile to make sure our instructions are clear and as easy to understand as possible. If you have any questions, comments, or suggestions don't hesitate to give our gear experts a call at 401.360.2550 or visit WWW.DENALIELECTRONICS.COM

Please Read Before Installing

DENALI products should always be installed by a qualified motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. DENALI takes no responsibility for damages caused by improper installation. **Caution:** When installing electronics it is extremely important to pay close attention to how wires are routed, especially when mounting products to the front fender, front forks, or fairing of your motorcycle. Always be sure to turn the handlebars fully left, fully right, and fully compress the suspension to ensure the wires will not bind and have enough slack for your motorcycle to operate properly.


Installation Tips

We strongly recommend using medium strength liquid thread locker on all screws, nuts, and bolts. It is also important to ensure that all hardware is tightened to the proper torque specifications as listed in your owner's manual. For included accessory hardware please refer to the default torque specifications provided below. Inspect all hardware after the first 30 miles to ensure proper torque specifications are maintained.


| Bolt Size | in-lbs | ft-lbs | Nm |
|-----------|-------------|-------------|---------|
| M3 | 10.0 in-lbs | - | 1.0 Nm |
| M4 | 23.0 in-lbs | - | 2.5 Nm |
| M5 | 44.5 in-lbs | 3.5 ft-lbs | 5.0 Nm |
| M6 | 78.0 in-lbs | 6.5 ft-lbs | 9.0 Nm |
| M8 | - | 13.5 ft-lbs | 18.0 Nm |
| M10 | - | 30.0 ft-lbs | 41.0 Nm |
| M12 | - | 52.0 ft-lbs | 71.0 Nm |

Hardware Sizing Guide

Not sure what size bolt you have? Use this ruler to measure screws, bolts, spacers, etc. Remember, the length of a screw or bolt is measured from the start of the "mounting surface" to the end of the screw, so only include the screw head when measuring countersunk screws.



What's In The Box?




Kit Contents

- (a) M6 x 25mm Flanged Button Head Screw DIN 7380.....Qty 2
- (b) Center S4 Light Mount Bracket.....Qty 1
- (c) Spacer OD:19mm ID: 6.53mm L: 8.2mm.....Qty 2
- (d) Oversized Washer OD-18mm ID-6.4mm H-1.6mm DIN 9021.....Qty 2

- (e) M6 Nyloc Nut DIN 985.....Qty 2
- (f) M8 x 12mm Socket Head Screw DIN 912.....Qty 1

Tools Required: 5mm Hex, 2.5mm Hex, 10mm wrench



1.1 - Location Prep & Installation

Step One: Remove the cover panel to gain access to the mounting location below the center of the headlight.

Note: This bracket will only work for bike models without Adaptive Cruise Control.

Step Two: The S4 Pod needs to be mounted to the Bracket (b) prior to its installation. Rotate the S4 Pod's hinge backwards so it's parallel to the pod face and secure it to the mounting tab using the M8 x 12mm Socket Head Screw (f).

Step Three: Position the Bracket (b) and Spacer (c) above the mounting shelf and align the mounting holes with the M6 x 25mm Flanged Button Head Screws (a). Secure the assembly together below the shelf with the Oversized Fender Washers (d) and Locking Nuts (e).